

FIG. 1

110a




FIG. 2

230

ERROR INFORMATION	BLOCK GAP SET VALUE
SERVO ERROR A	23
SERVO ERROR B	31
SERVO ERROR C	17
•	•
•	•
•	•

FIG. 3




FIG. 5




FIG. 4




FIG. 6




FIG. 7